



Operating Instructions

Rivet-Nut Speed Header Installation Tool

L6000/C6000/L7000/C7000



Pull-up stud

Handle

Barrel

Knob

Pull Knob completely out and place fastener onto pull-up stud (Fig. 1)



Hold Rivet-Nut Fastener with fingers, push knob into barrel of tool spinning Rivet-Nut so that all threads are engaged onto pull-up stud of the tool (Fig. 2).



Hold tool at a 90-Degree angle to work piece and place threaded Rivet-Nut into hole. Squeeze handle toward the barrel until resistance is felt (Fig. 3)



Thread Size	Ordering Part Number
4-40	L-6000-440
6-32	L-6000-632
8-32	L-6000-832
10-24	L-6000-1024
10-32	L-6000-1032
1/4-20	L-6000-2520
1/4-28	L-6000-2528
M3	L-6000-M3
M4	L-6000-M4
M5	L-6000-M5
M6	L-6000-M6

**Rivet-Nut Fasteners & tools are sold and serviced by:*



Enfasco Inc.

Engineered Fastener Company

Toll Free: (800)-820-7660

www.enfasco.com

E-Mail: sales@enfasco.com