



FIXTURE SHOWN IN DOWN POSITION.

INSTRUCTIONS FOR USE:

1. REMOVE PAPER FROM CENTRAL FOAM PAD.
2. APPLY STRAIN GAGE TO EXPOSED PRESSURE SENSITIVE ADHESIVE TAPE.
3. CLEAN AND PREPARE BONDING SURFACES.
4. APPLY MIXED ADHESIVE TO THE STRAIN GAGE BONDING SURFACE.
5. REMOVE PAPER FROM THE OUTER FOAM PADS.
6. LOCATE THE FIXTURE ON THE SUBSTRATE AND SECURE THE FIXTURE BY PRESSING ON THE OUTER BOX.
7. TOGGLE THE FIXTURE BY PRESSING ON THE INNER BOX, ACTIVATING THE FIXTURE.
THE FIXTURE WILL CONTROL THE BONDLINE THICKNESS DURING ADHESIVE CURE.
SUFFICIENT ADHESIVE SHOULD BE USED TO PROVIDE A SQUEEZEOUT AROUND THE ENTIRE PERIPHERY OF THE STRAIN GAGE.
8. WHEN THE ADHESIVE HAS CURED, REMOVE THE DISPOSABLE INSTALLATION FIXTURE.

EXAMPLE PART NUMBER

CB9268

↑ BASIC PART NUMBER

UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES AND TOLERANCES ARE AS SHOWN BELOW. DIMENSIONAL TOLERANCES AND SYMBOLS PER ANSI Y14.5M-1982.

PROPRIETARY PARTS SHOWN IN THIS DRAWING ARE THE SUBJECT OF ISSUED UNITED STATES AND FOREIGN PATENTS AND PATENTS PENDING. UNAUTHORIZED REPRODUCTION AND/OR DISTRIBUTION OF THIS DRAWING IS SPECIFICALLY PROHIBITED.

CLICK BOND

CARSON CITY
NEVADA 89706

		APPROVALS	DATE	TITLE		
ANGLES	±1°	DRAWN DAC	8JUN99	STRAIN GAGE INSTALLATION FIXTURE		
.XX	±.03	CHECKED DAC	8JUN99	SIZE	CAGE CODE	DWG. NO.
.XXX	±.010	RELEASED CGH	9JUN99	A	66530	CB9268
.XXXX	±.001	REVISED		SCALE	2/1	8JUN99
						SHEET 1 OF 1