



# FOR HD & HW ATTACHMENTS

FITS ALL HD & HW TOOLS WITH 5/16 DRIVER GEAR EXCLUDING SERIES 1



## TORQUE CONTROL INSTALLATION 1/8 AND 5/32 WRENCH TIPS



### LENGTH OF SOCKET

WRENCH TIP HEX	SOCKET HEX	DESCRIPTION	1/4	1/2	1	1 1/2	2	2 1/2	3
1/8	3/8	SOCKET ACCESSORY ASSEMBLY	15593	15594	15595	15596	15597	15598	15599
		SOCKET	15558	15559	15560	15561	15562	15563	15564
		JIFFY TIP 1/8 TORQUE	15670	15671	15672	15673	15674	15675	15676
	7/16	SOCKET ACCESSORY ASSEMBLY	15649	15650	15651	15652	15653	15654	15655
		SOCKET	15565	15566	15567	15568	15569	15570	15571
		JIFFY TIP 1/8 TORQUE	15670	15671	15672	15673	15674	15675	15676
	1/2	SOCKET ACCESSORY ASSEMBLY	15656	15657	15658	15659	15660	15661	15662
		SOCKET	15572	15573	15574	15575	15576	15577	15578
		JIFFY TIP 1/8 TORQUE	15670	15671	15672	15673	15674	15675	15676
	9/16	SOCKET ACCESSORY ASSEMBLY	15663	15664	15665	15666	15667	15668	15669
		SOCKET	15579	15580	15581	15582	15583	15584	15585
		JIFFY TIP 1/8 TORQUE	15670	15671	15672	15673	15674	15675	15676

### LENGTH OF SOCKET

WRENCH TIP HEX	SOCKET HEX	DESCRIPTION	1/4	1/2	1	1 1/2	2	2 1/2	3
5/32	7/16	SOCKET ACCESSORY ASSEMBLY	15816	15817	15818	15819	15820	15821	15822
		SOCKET	15565	15566	15567	15568	15569	15570	15571
		JIFFY TIP 5/32 TORQUE	15837	15307	15838	15839	15840	15841	15842
	1/2	SOCKET ACCESSORY ASSEMBLY	15823	15824	15825	15826	15827	15828	15829
		SOCKET	15572	15573	15574	15575	15576	15577	15578
		JIFFY TIP 5/32 TORQUE	15837	15307	15838	15839	15840	15841	15842
	9/16	SOCKET ACCESSORY ASSEMBLY	15830	15831	15832	15833	15834	15835	15836
		SOCKET	15579	15580	15581	15582	15583	15584	15585
		JIFFY TIP 5/32 TORQUE	15837	15307	15838	15839	15840	15841	15842

FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.